

ARMY RESEARCH LABORATORY



# Viewgraph Supplement to the Proceedings of the First Army Research Laboratory Acousto- Optic Tunable Filter Workshop

by Neelam Gupta

ARL-SR-54-S

March 1997

19970327 059

Approved for public release; distribution unlimited.

THIS QUARTER INTENDED 1

The findings in this report are not to be construed as an official Department of the Army position unless so designated by other authorized documents.

Citation of manufacturer's or trade names does not constitute an official endorsement or approval of the use thereof.

Destroy this report when it is no longer needed. Do not return it to the originator.

# Army Research Laboratory

Adelphi, MD 20783-1197

---

ARL-SR-54-S

March 1997

---

## Viewgraph Supplement to the Proceedings of the First Army Research Laboratory Acousto- Optic Tunable Filter Workshop

Neelam Gupta, Editor

Sensors and Electron Devices Directorate, ARL

---

Approved for public release; distribution unlimited.

---

---

## Abstract

---

Acoustic-optic tunable-filter (AOTF) technology is a recent development that offers potential for rapid, frequency-agile tuning over a large optical wavelength range. An AOTF is an electronically tunable phase grating set up in an anisotropic crystal by the propagation of an ultrasonic wave in the crystal. Such filters have many attractive features, such as small size, lightweight, computer controlled operation, large optical wavelength range of operation, and no moving parts; and their operation can be made ultrasensitive by the use of advanced signal processing algorithms. These filters are being used in many applications such as the design of new spectroscopic instruments, remote detection and monitoring of chemicals, optical communication networks, tuning of laser cavities, etc.

## Foreword

This volume, *Supplement to the Proceedings of the First Army Research Laboratory AOTF Workshop*, contains the viewgraphs that were presented at the conference.

Acousto-optic tunable filter technology (AOTF) has made significant progress in the last 30 years. These electronically tunable filters are finding many applications in various fields, such as chemical and environmental sensing, communications, hyperspectral imaging, pharmaceuticals, medicine, semiconductor processing, space exploration, etc. Due to their compact size and no moving parts, AOTF's offer numerous advantages over traditional grating-based technology. There is a tremendous potential offered by this technology, which remains to be fully utilized. One of the main motivations in organizing this workshop, the first of its kind, was to create a forum of experts and users that would provide the synergy to give a much needed impetus for the rapid development and exploitation of this promising technology.

In the Fall of 1995, I had the great privilege of visiting many Russian institutions involved in the research and development of this technology, and meeting with Russian scientists working in this field. This experience gave me the idea to bring U.S. and Russian scientists together for an intimate exchange of information and ideas for the advancement of AOTF technology. This workshop provided an avenue to implement this idea.

It has been a great deal of work to pull this workshop together, but the outcome has been worth many times the effort. It was a great experience to listen to the experts as well as the newcomers talk about AOTF basic research and applications for two full days.

I would like to thank my sponsors at the Army Materiel Command (AMC) and Army Research Laboratory (ARL) for providing the necessary funds to make this workshop possible. I would also like to thank every attendee for participating in this workshop, especially the Russian scientists for taking this long trip.

Neelam Gupta  
Army Research Laboratory  
Adelphi, MD, USA

# Contents

Foreword .....	i
Agenda .....	1
1. AOTF Technology: A Brief Overview .....	5
N. Gupta, Army Research Laboratory, USA	
2. Collinear AOTF Spectrometers: Problems, Results, and Methods of Measurements .....	17
V. I. Pustovoit, Central Bureau of Unique Instrumentation of Russian Academy of Sciences, Russia:	
N. Gupta, Army Research Laboratory, USA	
3. Recent Advances in AOTF Design and Fabrication at St. Petersburg State Academy of Aerospace Instrumentation .....	37
V. V. Kludzin, S. V. Kulakov, and V. V. Molotok, St. Petersburg State Academy of Aerospace Instrumentation, Russia	
4. Integrated Acousto-Optic Tunable Filters for Blue-Green Spectral Region .....	47
C. S. Tsai and A. M. Matteo, University of California, Irvine, USA	
5. Application of AOTF Technology for Chem/Bio Detection .....	59
N. Gupta and N. F. Fell, Jr., Army Research Laboratory, USA	
6. Factors Affecting AOTF Image Quality .....	79
L. J. Denes, B. Kaminsky, M. Gottlieb, and P. Metes, Carnegie Mellon Research Institute, USA	
7. An AOTF Camera for Multispectral Imaging .....	103
S. Aimizu, R. T. Obermyer, C. J. Thong, M. J. Uschak, and S. G. Sankar, Advanced Materials Corporation, USA; L. J. Denes, D. A. Purta, and M. Gottlieb, Carnegie Mellon Research Institute, USA	
8. Simultaneous Multispectral Imaging .....	123
J. A. Carter III and D. R. Pape, Photonics Systems Inc., USA:	
M. L. Shah, MVM Electronics Inc., USA	
9. Polarimetric Hyperspectral Imaging Systems and Applications .....	141
L.-J. Cheng, C. Mahoney, G. Reyes, and C. LaBaw, Jet Propulsion Laboratory, USA; G. P. Li, University of California, Irvine, USA	
Distribution .....	177
Report Documentation Page .....	179

# **First ARL Workshop on Acousto-Optic Tunable Filter Technology**

**Center for Adult Education, University of Maryland, College Park, MD**

**Tuesday, September 24, 1996**

## **AOTF Technology**

**Morning Session, Chair Andree Filipov, USARL-SEDD**

- 8:30 - 8:55    Check-in/Registration/Continental Breakfast**
- 8:55 - 9:00    Administrative Announcements**
- 9:00 - 9:20    Welcome & ARL Overview, John Pellegrino, Director, Sensors and  
Electron Devices Directorate, US Army Research Laboratory**
- 9:20 - 9:40    AOTF Overview, Neelam Gupta, USARL**
- 9:40 - 10:10   Progress in AOTF Technology, I. C. Chang, Aurora Associates, Santa  
Clara, CA**
- 10:10 - 10:40   Break**
- 10:40 - 11:10   Collinear AOTF Spectrometers: Problems, Results, Methods of Spectral  
Measurements, V. I. Pustovoi, Central Bureau of Unique Instrumentation,  
Moscow, Russia, and N. Gupta, USARL**
- 11:10 - 11:40   Recent Advances in AOTF Design and Fabrication at SPSAAI, V. V.  
Kludzin, S. V. Kulakov, and V. V. Molotok, St. Petersburg State Academy  
of Aerospace Instrumentation, St. Petersburg, Russia**
- 11:40 - 1:00    Lunch**

**Afternoon Session, Chair Neelam Gupta, USARL-SEDD**

- 1:00 - 1:30    Application of AO Interaction for Filtration of Arbitrary Polarized  
Radiation, V. Voloshinov, Physics Department, Moscow State University,  
Moscow, Russia**
- 1:30 - 2:00    Improvement of Resolution of Visible AOTF in TeO<sub>2</sub>, V. Pelekhaty,  
Brimrose Corp. Of America, Baltimore, MD**
- 2:00 - 2:30    Growth of Acousto-optic Crystals with High Anisotropy and Development  
of Multichannel Acousto-optical Processors, Y. B. Pisarevsky**

- 2:30 - 3:00    **Break**
- 3:00 - 3:30    **Progress in AOTF Technology for WDM Systems, D. Smith, Case Western Reserve University, Cleveland, OH**
- 3:30 - 4:00    **Integrated AOTF for Blue-Green Spectral Region, C. S. Tsai and A. M. Matteo, University of California, Irvine, CA**
- 4:00 - 5:00    **AOTF Demonstrations**
- 6:30            **Banquet, University Of Maryland, College Park**

**Wednesday, September 25, 1996**  
**AOTF Applications**

**Morning Session, Chair Andrzej Miziolek, USARL-WMRD**

- 8:30 - 9:00    **Registration/Continental Breakfast**
- 9:00 - 9:30    **Application of AOTF in Analytical Chemistry, C. D. Tran, Marquette University, Milwaukee, WI**
- 9:30 - 10:00    **Application of AOTF Technology for Chem/Bio Detection, N. Gupta and N. F. Fell Jr., US Army Research Laboratory, Adelphi, MD**
- 10:00 - 10:30    **Break**
- 10:30 - 11:00    **An AOTF-Based Near-Infrared Spectrometer for Process Control, S. Medlin, U. Eschenaur, and W. Danley, Brimrose Corp. Of America, Baltimore MD**
- 11:00 - 11:30    **Application of AOTF to Near IR Spectroscopy and High Fidelity Spectroscopic Imaging, E. N. Lewis, National Institutes of Health, Bethesda, MD**
- 11:30 - 1:00    **Lunch**

**Afternoon Session, Chair James Gillespie, USARL-ISTD**

- 1:00 - 1:30    **Factors Affecting AOTF Image Quality, L. J. Denes, B. Kaminsky, M. Gottlieb, and P. Metes, Carnegie Mellon Research Institute, Pittsburg, PA**



- 1:30 - 2:00    **An AOTF Camera for Multispectral Imaging, S. Simizu, R. T. Obermyer, C. J. Thong, M. Uschak, S. G. Sankar, Advanced Materials Corp., Pittsburg, PA, D. J. Denes, D. A. Purta, and M. Gottlieb, Carnegie Mellon Research Institute, Pittsburgh, PA**
- 2:00 - 2:30    **Simultaneous Multispectral Imaging with a 12 Parallel Channel Tunable Camera, J. A. Carter III, D. R. Pepe, Photonics Systems, Inc., Melbourne, FL, and M. L. Shah, MVM Electronics, Inc., Melbourne, FL**
- 2:30 - 3:00    **Break**
- 3:00 - 3:30    **Polarimetric Hyperspectral Imaging Systems, L.-J. Cheng, G. Reyes, and C. La Baw, Jet Propulsion Laboratory, CA, and G. P. Li, University of California, Irvine, CA**
- 3:30 - 4:00    **Multiplexing Methods in AOTF Multispectral Imaging, P. Treado, and J. Turner, University of Pittsburgh, Pittsburgh, PA**
- 4:00 - 4:30    **Remote Spectral Imaging System Based on an AOTF, T. Vo-Dinh, Oak Ridge National Laboratory, Oak Ridge, TN**
- 4:30            **Workshop Closing**

# **AOTF TECHNOLOGY: A BRIEF OVERVIEW**

---

***Dr. Neelam Gupta***

**Sensors & Electron Devices Directorate  
Army Research Lab  
Adelphi, MD 20783**

**FIRST ARL WORKSHOP ON  
AOTF TECHNOLOGY  
24-25 September 1996**

Center for Adult Education, University of Maryland

**ARMY RESEARCH LABORATORIES**

# INTRODUCTION

---

## **What is an AOTF:**

A moving diffraction grating is set up in an anisotropic crystal, when an acoustic beam propagates through it as a result of an applied rf field. When light is incident on this grating, it is diffracted with polarization orthogonal to the incident beam for only a specific incident wavelength as a result of the acousto-optic interaction. The wavelength can be tuned by varying the rf frequency, forming an electrically tunable optical filter. Such an optical filter is called an Acousto-Optic Tunable Filter (AOTF).

**Collinear AOTF:** Incident light, sound and diffracted light beams all propagate in the same direction.


**Noncollinear AOTF:** Incident light, sound and diffracted light beams do not propagate in the same direction.

# COLLINEAR AOTF

---



---




$$k_{diff} = k_{in} + q$$

$$\lambda = (n_o - n_e)v_s/\Omega$$

$$\text{Spectral Resolution } \Delta\lambda/\lambda = \lambda/L\Delta n$$

# NONCOLLINEAR AOTF



# AOTF MILESTONES

---

- 1922 Brillouin      Theoretical Prediction of AO Interaction
- 1932 Debye, et al.      Experimental Demonstration of AO Interaction
- 1955 Rosenthal      Theoretical Discussion of Color Control by  
                                 Ultrasound Grating
- 1967 Dixon      Acoustic Diffraction of light in Anisotropic Media
- 1969 Harris, et al.      Collinear AOTF
- 1968 Arlts, et al.      Synthesis of  $\text{TeO}_2$
- 1971 Nieh et al.      Analysis of Collinear AOTF
- 1973 Kusters, et al.      Optimization for AOTF
- 1974 Chang      Noncollinear AOTF in  $\text{TeO}_2$
- 1977 Ohmachi, et al.      Integrated Optic AOTF
- 1987 Pustovoit, et al.      Ocean Satellite Trasser Apparatus

# AOTF ADVANTAGES

---

10

- Lightweight, Compact, Portable
- No Moving Parts, Rugged
- Reliable
- Reproducible Operation
- Rapid Tuning and Scanning
- Low Drive Power
- All Solid State Operation
- High Spectral Resolution
- Polarization Separation
- Broad Tuning Range
- Wide FOV
- High Throughput
- Sequential or Random  $\lambda$  Access
- Capability for Multi  $\lambda$  Operation
- High Signal-to-Noise Ratio
- Uncooled Operation
- Programmable, Computer Control
- Arbitrary Spectral Signal Generation

# **AOTF APPLICATIONS**

---

- Sensing of Chemical & Biological Agents: Fluorescence, Absorption, emission, Raman, LIBS, etc.
- Remote Sensing/ Environmental Monitoring
- Multispectral and Hyperspectral Imaging
- Medical Applications; i.e. Cancer Detection
- Tuning of Laser Wavelength
- Process and Quality Control
- Astronomical Observations
- Communication; i.e. WDM



## AOTF APPLICATIONS (Continued)

---

- Polarization Spectroscopy
- Fire Sensing
- Water Quality Monitoring on Space Station
- Spectroscopy on Comet Lander
- Spectroscopy on Mars Lander
- Cassini Mission to Saturn
- Others ??????
- Under water Spectroscopy

# KEY ELEMENTS IN AOTF SYSTEM DESIGN

---

---

- Material Selection
- Crystal Geometry
- Transducer Design
- AOTF Cell Architecture
- Electronics
- Computer Interface
- Processing Software

# Spectral Coverage/Materials

14

Spectral Bands Covered ( $\mu\text{m}$ )	Material	Type
0.4 - 4.5	$\text{LiNbO}_3$	Collinear
0.25 - 0.8	Xtal Quartz	Collinear
0.2 - 0.7	$\text{MgF}_2$	Collinear
0.4 - 4.5	$\text{CaMoO}_4$	Collinear
0.35 - 4.5	$\text{TeO}_2$	Noncollinear
1.1 - 17	$\text{Tl}_3\text{AsSe}_3$	Collinear or Noncollinear
0.35 - 20	$\text{Hg}_2\text{Cl}_2$	Noncollinear

## KEY PLAYERS IN AOTF TECHNOLOGY

---

- **US Govt:** ARL, ERDEC, JPL, NASA, NIH, ORNL, etc.
- **US Univ:** Case Western Univ, Marquette Univ. WI, UC Irvine, Univ. of Pittsburg, etc.
- **US Companies:** ATT Labs, Aurora Assoc, Advanced Materials Corp., Brimrose Corp. of America, Carnegie Mellon Research Institute, Neos, Photonics Systems, etc.
- **Russia:** CBUI, Inst. of Xtallography, SPAAI, MSU, etc.
- **Others:** Matsushita Electronics, Japan; France, U.K.

# AOTF TECHNOLOGY STATUS/CHALLENGES

---

16


- Very Promising Technology
- Much Progress in Visible/NIR
- Labor Intensive Fabrication
- Improvement of Existing Material, i.e.  $\text{TeO}_2$
- Development of New Materials for UV/ Long IR
- Novel designs, i.e. Implement Backward Diffraction
- Reduce Cost
- Automate Fabrication
- Find New Applications


# **Collinear AOTF Spectrometers: Problems, Results, and Methods of Measurements**

by

*V. I. Pustovoit*, Central Bureau of Unique  
Instrumentation of Russian Academy of Sciences, Russia; &  
*N. Gupta*, Army Research Laboratory, USA

## OPTICAL SCHEME OF AO SPECTROMETERS














**AO Spectrometer  
for airborne and surface-based  
platforms**







*Acousto-optical Spectrometer of visible and UV bands*




## Specifications:


Spectral Range, nm	415 to 790
Resolution, nm	0.10 to 0.25
Wavelength measurement instrumental error, nm	$\pm 0.15$
Sensitivity, W	10-12
Dynamic range, dB	45
Minimum measurement time at one spectral point, ms	32
Max. number of spectral points	4096
Input angle	2 degrees
Input window	$\phi$ 6 mm






JS2\_1









# Black Sea and Land H=1000m










**Murmansk, 31.08.90**  
**time from 11.52 - 13.26**



- 11:52:38
- 12:02:17
- 12:05:13
- 12:06:58
- 12:13:45
- 12:19:13
- 12:22:25
- 12:26:08
- 12:29:58
- 12:32:57
- 12:42:59
- 12:44:59
- 12:46:57
- 12:52:14
- 12:56:15
- 13:05:58
- 13:07:58
- 13:08:11
- 13:11:25
- 13:12:27
- 13:14:19
- 13:15:59
- 13:26:57

# SEA OF AZOV DATA POINTS






Enhanced spectral resolution derived from  
special analysis of spectrogram


27/06/1995 16:22:35

# Spectrum measurement




## Raman Spectrum of TCE

## Human and Sea-gull Vision System




*The curves of sensitivity of eyes (photodetectors) has three fixed maximums*

*The curves of sensitivity of eyes (photodetectors) of Sea-Gull vision system has three fixed maximums, which can move on spectral axis*



## Acousto-Optical System for the transmission, processing, and recognition of images




(V.E.Pozhar and V.I.Pustovoi.  
Радиотехника и электроника, 1996, v.41, №10)

## Pollution Detection Threshold

Measured pollutant	SAGA-K		SAGA-T	
	Detection Threshold, ppm, not greater, cell 75cm	Maximum measured concentration ppm, not greater, cell 20cm	Detection Threshold, ppm, not greater, path 200m	Maximum measured concentration ppm, not less, path 30m
Sulfur dioxide, SO <sub>2</sub>	2	4500	0,02	50
Nitrogen dioxide, NO <sub>2</sub>	5	3000	0,02	40
Carbon disulphide, CS <sub>2</sub>	14	4000	0,02	100
Ozone, O <sub>3</sub>	20	5000	0,02	100
Chlorine, Cl <sub>2</sub>	20	6000	0,1	100
Formaldehyde, H <sub>2</sub> CO	20	6000	0,1	100
Benzene, C <sub>6</sub> H <sub>6</sub>	2	1000	0,03	10
Toluene, C <sub>6</sub> H <sub>5</sub> -CH <sub>3</sub>	3	1500	0,04	15
Phenol, C <sub>6</sub> H <sub>5</sub> OH	0,6	100	0,003	1
Naphtalene, C <sub>10</sub> H <sub>8</sub>	0,7	120	0,003	0,5
Pyrene, C <sub>16</sub> H <sub>10</sub>	0,3	12	0,002	0,3
p-Xylene, C <sub>8</sub> H <sub>10</sub>	100	2000	0,5	250
m-Xylene, C <sub>8</sub> H <sub>10</sub>	2	1200	0,03	12
o-Xylene, C <sub>8</sub> H <sub>10</sub>	4	3000	0,06	30
Acetone, (CH <sub>3</sub> ) <sub>2</sub> CO	10	5000	0,3	50



# OPTICAL SCHEME OF ATMOSPHERIC POLLUTION MEASUREMENT




# **Recent Advances in AOTF Design and Fabrication at St.Petersburg State Academy of Aerospace Instrumentation**

**V.V.Kludzin, S.V.Kulakov, V.V.Molotok**  
*St. Petersburg State Academy of Aerospace Instrumentation,  
Laboratory of Acousto - Optic Systems,  
67 B.Morskaia St., St.Petersburg, 190000, Russia,  
Phone/FAX: +7 (812) 108-4204, E-mail:molotok@softjoys.ru*

---


- 1. The main advantages of the acoustooptic tunable filters (AOTF)**
  - 1. Controllable tuning by an electronic signal**
  - 2. Fast switching speed**
  - 3. Extended angular aperture**
  - 4. Compatibility with electronic analog and digital modules**
  - 5. simple design and small sizes**

#### 4. AOTF used for modulating spectrum width of a wideband optical signal.




$$T \leq D/v - \text{clock rate}$$

$$0 < \tau < T; \quad \delta\lambda = k\tau$$




a) ( $\tau=T$ )




b) ( $\tau=0.5T$ )

**Fig.4. Spectral responses of  $\text{CaWO}_4$  collinear AOTF**



a) ( $\tau=0.5T; T=0.5D/v$ )



b) ( $\tau=0.5T; T=0.25D/v$ )

**Fig.5**

## 5. AOTF used in spectrometry

Table 4. Spectrometer parameters

AOTF materials	Analysis range, $\mu\text{m}$	Control frequency range, MHz	Resolution, nm ( $\lambda=0.63 \mu\text{m}$ )	Transmission coefficient	Analysis time, ms	Interaction regimes
Water	0.4-0.7	28-50	2.5	0.5 $P \approx 0.1 \text{ W}$	$\geq 2$	Isotropic
PbMoO <sub>4</sub>	0.6-1.1	90-160	1.5	0.5 $P \approx 0.5 \text{ W}$	1	Isotropic
LiNbO <sub>3</sub>	0.5-1.0	7-14	6	0.65 $P \approx 0.2 \text{ W}$	1	Sub-collinear
TeO <sub>2</sub>	0.65-1.5	25-55	1.2	0.8 $P \approx 0.05 \text{ W}$	$> 3.5$	Quasi-collinear
CaWO <sub>4</sub>	0.56-1.04	35-65	1.1	0.5 $P \approx 0.5 \text{ W}$	5	Collinear $\Delta\psi \approx 4.5^\circ$




Fig. 6




Fig.8




Fig.7

## **Conclusion**

- 1. Acousto-optic tunable filter have several advantages resulting from their electronic control and a large variety of available materials regimes.**
- 2. The anisotropic regimes of acoustooptic interaction seems to be more perspective for the most applications.**
- 3. In some cases, the advantages of isotropic media are worth remembering.**

## **References**

- Design and Fabrication of Acoustoptic Devices. Ed.by A.Goutzoulis, D.Pape. Marcel Dekker Inc., New York, 1994**
- Dixon R.W. Acoustic diffraction of light in anisotropic media. IEEE Journ., QE-3, #2, 1967, p.85-93**
- Nien S.T.K., Harris S.E. Aperture-bandwidth characteristics of the filter. JOSA, 1972, v.62, #5, p.62-676**
- Yano T., Watanabe A. New noncollinear acoustooptic tunable filter using birefringence in TeO<sub>2</sub>. Appl. Phys. Letters, 1978, v.24,#6, p.256-258**
- Chang I.C. Noncollinear acoustooptic filter with large angular aperture. Appl. Phys. Letters, 1974, v.25, p.370-373**
- Sivanaygam A., Findlay D. High resolution noncollinear acoustooptic filters with variable passband characteristics: design. Appl.Optics, 1984, v.233, #24, p.4601-4608.**

**Table 2. Physical parameters of acousto-optic materials**

Material	Transparency range, $\mu\text{m}$	Refraction index ( $\lambda=0.63 \mu\text{m}$ )	Acoustic velocity $v \cdot 10^5 \text{ cm/sec}$	Figure of merit, $M_2 \cdot 10^{-18} \text{ c}^3/\text{g}$	Range of control frequencies, MH ( $\lambda=0.63 \mu\text{m}$ )	Possible interaction regimes
$\text{TeO}_2$	0.36 - 5	$n_0=2.26$ $n_e=2.41$	0.617	600 - 1000	50 - 100	w/o collinear
$\text{LiNbO}_3$	0.4 - 4.5	$n_0=2.28$ $n_e=2.2$	3.9 6.57	3 - 8	400 - 600	all regimes
$\text{CaWO}_4$ ( $\text{CaMoO}_4$ )	0.4 - 4.5	$\Delta n =  n_0 - n_e  = 0.016$	2.3	$\sim 10$	60	collinear
$\text{SiO}_2$	0.15 - 4	$n_0=1.542$ $n_e=1.551$	5.75	$\sim 2$	80	all regimes
$\text{Ti}_3\text{AsSe}_3$	1.25 - 17	$n_0=3.38$ $n_e=3.19$ ( $\lambda=1.5 \mu\text{m}$ )	1.0	$\sim 700$	100 ( $\lambda=1.5 \mu\text{m}$ )	all regimes

### 3. Normalization of the spectral response

For "slow" scanning regime

$\delta\lambda \sim \lambda^2$ ;  $N = \Delta f D / v$  - number of resolvable points

Result of normalization

$$\delta\lambda(\lambda) = \delta\lambda(\lambda_{\max}) = \text{Const}$$

$$\text{if } f(t) = f_0 + bt^2$$

$$T = (N)^{0.5} D / v$$




Fig.2. Collinear AOTF

## 2. The main parameters of AOTF









Fig.3. The spectral responses of AOTF ( $\lambda_0=0.63 \mu\text{m}$ )



Table 1. The geometry of different regimes of acousto-optic interaction

1		$\lambda f = n v \sin \Theta_0$ $k_a = \frac{2\pi f}{v}, \quad k_i = k_d = \frac{2\pi n}{\lambda}$ $\delta \lambda \approx \frac{\lambda^2}{D \sin \Theta_0}$ <p><i>isotropic</i></p>
2		$\lambda f = \Delta n_0 v \sin \Theta_i$ $k_i = \frac{2\pi n_i}{\lambda}, \quad k_d = \frac{2\pi n_d}{\lambda}$ $\delta \lambda \approx \frac{\lambda^2 \cos \Theta_i}{\Delta n_0(\lambda) L \sin^2 \Theta_i}$ <p><i>quasicollinear</i></p>
3		$\lambda f \approx v \frac{\Delta n(\lambda, \Theta_i)}{\cos \Psi}$ <p><i>subcollinear</i></p>
4		$\lambda f = \Delta n v \sqrt{(\sin^4 \Theta_i + \sin^2 2\Theta_i)}$ $\delta \lambda \approx \frac{\lambda^2 \cos(\Theta_a - \Theta_i)}{\Delta n_0(\lambda) L \sin^2 \Theta_i}$ $\operatorname{tg} \Theta_i \operatorname{tg}(\Theta_a - \Theta_i) = 2$ <p><i>Tangential</i></p>
5		$\lambda f = \Delta n(\lambda) v$ $\delta \lambda = \frac{\lambda^2}{\Delta n(\lambda) L}$ <p><i>collinear</i></p>

$$\Delta \Psi R = \text{const}$$




Fig.1. The isotropic acoustooptic tunable filter

$$d \leq \frac{k\lambda F}{D} \quad R_s = \frac{fD}{v} \quad R_o = \frac{fL}{v} \tan \Theta_o,$$

$$R_i = R_o \rightarrow \frac{\delta\lambda}{\lambda} = \frac{0.66}{R}, \quad g(\lambda) \sim \left\{ \text{sinc} \left[ \pi R \left( \frac{\lambda}{\lambda_o} - 1 \right) \right] \right\}^4$$


### The advantages of isotropic interaction

1. The independence to the polarization of the input optical signal
2. More materials can be used in manufacturing of devices under different technical requirements
3. Large angular aperture in the plane orthogonal to the acousto-optic interaction plane
4. The isotropic materials are comparatively less expensive and their workpieces can be larger

# **Integrated Acousto-Optic Tunable Filters for Blue-Green Spectral Region**

by

**C. S. Tsai and A. M. Matteo, University of California, Irvine,**






Fig. 2




Fig. 3





Fig. 2








Fig. 6







Fig. 7







# **APPLICATION OF AOTF TECHNOLOGY FOR CHEM/BIO DETECTION**

---

---


***Dr. Neelam Gupta & Dr. N. F. Fell, Jr.***

**Sensors & Electron Devices Directorate  
Army Research Lab  
Adelphi, MD 20783**

**FIRST ARL WORKSHOP ON  
AOTF TECHNOLOGY  
*24-25 September 1996***

Center for Adult Education, University of Maryland

## COLLINEAR AOTF



$$f_{diff} = f_{in} + \Omega$$

$$k_{in} - k_{diff} - q = 0$$

$$\lambda = (n_o - n_e)v_s / \Omega$$

$$\text{Spectral Resolution } \Delta\lambda/\lambda = \lambda L \Delta n$$

## EXAMPLE: CRYSTAL QUARTZ AOTF

---

$$n_o = 1.548, n_e = 1.539$$

$$V_s = 6.0 \times 10^5 \text{ cm/sec}$$

for visible band  $400 \text{ nm} < \lambda < 800 \text{ nm}$

$$135 \text{ MHz} < \Omega_{\text{sound}} < 68 \text{ MHz}$$



## **COLLINEAR AOTF ADVANTAGES**

---

- Lightweight, Compact, Portable
- No Moving Parts, Rugged
- Reliable
- Reproducible Operation
- Rapid Tuning and Scanning
- All Solid State Operation
- High Spectral Resolution
- Polarization Separation
- High Extinction Ratio
- Broad Tuning Range
- High Throughput
- Sequential or Random  $\lambda$  Access
- Capability for Multi  $\lambda$  Operation
- High Signal-to-Noise Ratio
- Uncooled Operation
- Programmable, Computer Control
- Arbitrary Spectral Signal Generation
- Flexible

## AOTF Specifications


	Quartz 4	Visible	UV
Spectral Range (nm)	420-785	400-800	255-430
Resolution (nm)	0.12-0.5	0.1-0.54	0.05-0.2
Position error (nm)	$\pm 0.5$	$\pm 0.2$	$\pm 0.2$
Max Number of Points	4096	4790	7892
ADC Range	10 bits	12 bits	12 bits
Amplification	31	15	15
PMT Voltage Sensitivity	-	1:3:9:30	1:3:9:30
Effective Dynamic Range	31,744	1,843,200	1,843,200
Aperture	6 x 6 mm	6 x 6 mm	6 x 6 mm
Field of View	2°	2°	2°

## AOTF APPLICATIONS AT ARL


---

- Sensing of Chemical & Biological Agents: Fluorescence, Absorption, Emission, Raman, LIBS, etc.
- Remote Sensing/ Environmental Monitoring
- Multispectral and Hyperspectral Imaging
- Medical Applications; i.e. Blood Analysis
- Fire Sensing
- Polarization Spectroscopy


# OPTICAL SCHEME OF ACOUSTIC SPECTROMETER "QUARTZ - 4"




# AOTF Spectrometer System




Hg Lamp AOTF Spectra  
Amp 1, PMT 1, Accum 1,  
max. number of points



# Hg Lamp UV Resolution




# Hg Lamp Visible AOTF Resolution











# Sunlight through Window with AOTF


Amp 3, PMT 2, Accum 50, 4790 points



# Fluorescein in Methanol Fluorescence


Corrected for laser power and PMT setting






# 1e-7 M Fluorescein in MeOH

Quartz 4, 260 mW, Amp 31, 10 Accum




# 1e-7 M Fluorescein in MeOH

New AOTF, 260 mW, PMT 4, Amp 1, 10 Accum




# Naphthalene Solid Raman Spectrum w/AOTF

Ex. 514.45 nm, Amp 15, PMT 4, Accumulation 100, 1.25 W




# Naphthalene in Capillary Tube FT-Raman

Ex. 1064 nm, 400 mW, 128 co-adds, 4 cm<sup>-1</sup> Resolution



# BT-containing Insecticide in Quartz Cuvette

Ex. 260 nm, Amp 15, PMT 4, Accum 100



## **SUMMARY**

---

- Characterized Performance for three UV/VIS spectrometers.
- Obtained Results for Fluorescence Measurements.
- Obtained Results for Raman Scattering
- Evaluating Instruments for Stand-off Chem/Bio Detection.
- Mid-IR AOTF being Developed.
- Imaging Experiments Planned.
- Polarization Experiments Planned.
- Fire Sensing Proposed.



# **FACTORS AFFECTING AOTF IMAGE QUALITY**

**L.J Denes, Boris Kaminsky, M. Gottlieb and P. Metes**

**Carnegie-Mellon Research Institute  
Pittsburgh, Pennsylvania**

**This work was supported under U.S. Army SBIR subcontract, No.  
DAAB07-93-C-0005, and U.S. Navy contract N00014-95-1-0591**

## Image Blur Relation to $\theta_i$ and $L$

For small values of  $n_i - n_d$  and  $\Theta_i - \Theta_d$ , the non-critical phase matching (NPM) condition can be approximated as

$$\lambda_0 / \Lambda = n_0 (\Theta_i - \Theta_d)$$

The usual NPM approximation for tuning is

$$\lambda_0 / \Lambda = \Delta n (\sin^4 \Theta_i + \sin^2 2\Theta_i)^{1/2}$$

so that an approximation to the beamspread is

$$\Delta \Theta_d / \Delta \lambda = (\Delta n / n_0 \lambda_0) (\sin^4 \Theta_i + \sin^2 2\Theta_i)^{1/2}$$


This approximation agrees well with the exact calculations.

It is straightforward to recast the dependence on the transducer length by substituting for  $\Delta \lambda$

$$\Delta \lambda = 1.8\pi\lambda^2 / (\Delta n \cdot L \sin^2 \Theta_i)$$


to obtain

$$\Delta \Theta_d = ((\sin^4 \Theta_i + \sin^2 2\Theta_i)^{1/2} / \sin^2 \Theta_i) (1.8\pi\lambda) / nL$$




Calculated internal beam spread due to the filter bandpass for various noncollinear TAS AOTF configurations.

# ACOUSTIC BLUR IS MINIMIZED BY PROPER CHOICE OF TRANSDUCER LENGTH



$$\theta_i = 12^\circ, \theta_a = 5.9^\circ, \theta_r = 16.35^\circ$$



Infrared resolution target for imaging system.




Figure 5. Infrared target image (a) without AOTF, and (b) with noncollinear AOTF.

## AOTF-1 Parameters

$$\Theta_1 = 12 \text{ degrees}$$

$$\Delta\theta_1 = 6.5 \text{ degrees (ext)}$$

$$\Theta_a = 5.9 \text{ degrees}$$


$$L_1 = 0.33 \text{ cm}$$

$$L_2 = 0.66 \text{ cm}$$


$$L_3 = 1.32 \text{ cm}$$

$$L_4 = 2.32 \text{ cm}$$

$$\Delta\lambda/\lambda = .01 \text{ (for } L = 2.32 \text{ cm)}$$








2.5 lp/mm




**IMAGE EVALUATION  
TEST TARGET (MT-11)**




**STANFORD  
COMPUTER OPTICS, Inc.**  
*The eyes of your computer*


2000 Regentway Lane  
Belmont, Mass. 02459

Tel & Fax (617) 755-7022  
In Europe Tel & Fax 011 40 80 05 40 17





# CONTRIBUTIONS TO AOTF BACKGROUND: PRIMARY ACOUSTIC BEAM VS REFLECTED ACOUSTIC BEAM



## Scattering

The ratio of scattered light intensity to diffracted image signal is approximately

$$I_{\text{scat}} / I_{\text{image}} = S \cos^2 \phi (\Delta\lambda \delta\lambda) + (p \eta)$$

where:

$S$  = scattering coefficient

$\phi$  = scattering angle

$\delta\lambda$  = AOTF resolution


$\Delta\lambda$  = spectral range of light source and detector

$p$  = polarization loss, at least 50%

$\eta$  = AOTF efficiency

For a typical AOTF design,  $S \sim 10^{-5}$ ,  $(\Delta\lambda \delta\lambda) = 100$ ,  $p = 0.5$ , and  $\eta = 0.5$ , and  $\cos^2 \phi \sim 1$ , so that the estimated scattered light intensity is about 24 dB below the image signal.

## LASER LIGHT SCATTERING FROM TYPICAL AOTF





# Multi-spectral Imaging



---

## Where are we going ?

---

## Targets

• Wavelength tunability:	1 -> 2 Octaves
• Field of view	2-12°
• Spectral resolution:	10-20 nm, $\Delta\lambda/\lambda = (0.1 - 1)\%$
• Spatial resolution:	< 1 $\mu$ radian
• Background:	Limited by camera noise

---


## Critical Parameters

- Optical system configuration
  - AOTF (design & fabrication)
- Suppression of:
  - Blur
  - Ghost images
  - Broadband background
- Transducer design
- Transducer fabrication
- AR coatings







## Imaging A-O Spectrometer





# SPECTRAL RESOLUTION OF NEOS 4-3-P-1 AOTF



# SPECTRAL RESOLUTION OF NEOS 4-3-S-1 AOTF




# Multi-spectral Imaging




# SPECTRAL RESOLUTION OF NEOS 4-3-S-1 AND 4-3-P-1 AOTF IN



SERIES



# Second Generation Imaging A-O Spectrometer



# Multi-spectral Imaging



---

## Conclusions

- Image quality is limited by blur, side lobes and broadband scattering
- Our two AOTF configuration offers a solution to the above problems
- Present work was performed in the VIS & NIR, Future work is planned to include the Mid & Far IR



## **An AOTF Camera for Multispectral Imaging**

**S. Simizu, R. T. Obermyer, C. J. Thong, M. J. Uschak, and S. G. Sankar**  
**Advanced Materials Corporation**  
**700 Technology Drive, Pittsburgh, PA 15230**

**and**

**L. J. Denes, D. A. Purta, and M. Gottlieb**  
**Carnegie Mellon Research Institute**  
**Pittsburgh, PA 15230**

**\* Supported by the US Army under Contract No. DAAB07-95-C-M042**

## **Overview**

### **1. Camera System**

**Defining Optics**

**AOTF Design**

**Camera/Imaging Hardware**

**RF Drive**

### **2. System Performance**

**Filter Characteristics**


**Blur/Background**

### **3. Target Identification**

**Image Pre-processing by AOTF**


**Processing Speed**

**Advanced Material Corp.**



**A block diagram of the AOTF camera system**

**Advanced Material Corp.**




### Defining Optics

- 8 -- 80 mm motorized (focus, zoom, iris) zoom lens
- Rectangular stop to match  $2.5^\circ$  separation angle of the AOTF
- 50 mm collimation lens
- FOV  $1.6^\circ$  --  $15.6^\circ$

### AOTF Crystal

- AMC/CMRI design
- Three parallel transducers
- Vertical diffraction (CCD less sensitive to vertical blur)




### R.F. Source

- Tektronix AWG2040 arbitrary waveform generator
- 1.024 GS/s
- 1 Meg of waveform memory
- 8 bits output
- 2 V maximum amplitude

### Camera Lens

- 60 -- 300 mm zoom lens
- 135 mm present position




## Camera


- DVC Model DVC-10
- SNR of 62 db at 0.5 lux
- Spectral range of 0.45 -- 1.0  $\mu$
- 755 x 484 pixels
- Simultaneous 10 bit parallel and analog video
- Real time capability of 30 frames per second
- On camera digitization

Nominal Specifications for  
TeO<sub>2</sub> Acousto-optical tunable filter


Designed by:

Louis J. Denes and Milt Gottlieb  
Carnegie Mellon Research Institute






(a)




(b)



(c)


Fig. 6. Different characteristics of AOTF for three RF driving waveforms:  
 (a) Driven by a single sinusoidal wave at 63.57 MHz;  
 (b) Driven by a combination of two sinusoidal waves at 60.85 MHz and 63.57 MHz;  
 (c) Driven by a spread RF spectrum in the range of 59.03 MHz to 67.21 MHz.






Unfiltered Image

Advanced Material Corp.





**0.19 Watts**





**0.65 Watts**


**Advanced Material Corp.**














**Unfiltered Image**

**Advanced Material Corp.**












**(a) Filtered at 643 nm**



**(b) Filtered at 603 nm**



**(c) Processed Image**

**Advanced Material Corp.**



# **Simultaneous Multispectral Imaging**

---



## **Simultaneous Multispectral Imaging with 12 Parallel Channel Tunable Camera**

**J. A. Carter III, D. R. Pape,**  
**Photonic Systems Inc., Melbourne, Florida**  
URL <http://photon-sys.com/>

**M. L. Shah,**  
**MVM Electronics, Inc., Melbourne Florida**

# **Simultaneous Multispectral Imaging**

---



**Photonic Systems  
Incorporated**

## **Introduction**

- **Background and Chronology**
- **Simultaneous Multispectral Imaging System (SMIS) Description**
- **SMIS Design Methodology**
- **Compensation Error Residuals for Increasing Design Freedom**
- **Acoustic Transducer Design**
- **Prototype Performance**
- **Conclusion**
- **Credits**

# Simultaneous Multispectral Imaging

---



Photonic Systems  
Incorporated

## Background and Chronology

- July of 1992, PSI and MVM jointly proposed "*A Simultaneous electronically variable Multi-spectral Imaging System*" to NASA JPL as a Phase I SBIR effort that was funded as Contract NAS7-1222.
- August of 1993, the Phase II proposal describing the development of the Simultaneous Multispectral Imaging System (SMIS) was submitted
- April of 1994, NASA JPL funded the contract as NAS7-1311.
- April of 1996, Prototype AOTF and compensation optics set were presented at the SPIE AeroSense Technical Exhibit to provide a preliminary demonstration of these technologies.
- PSI and MVM are now completing that system.

# **Simultaneous Multispectral Imaging**

## **Simultaneous Multispectral Imaging System**



**Photonic Systems  
Incorporated**

- **Fully compensated AOTF based imager.**
- **Simultaneous imaging of multiple spectral bands on separate image sensors.**
- **Extensible design to allow additional band channels as well as broadband imaging.**
- **Image data for polarimetric scenes or non-polarimetric scenes with double the number of bands.**
- **Astronomical imaging for NASA prototype system.**
  - **2 polarization channels**
  - **6 image band channels**
  - **2 AOTF nodes**
  - **3 image channels separated by dichroic filters**
  - **512 x 512 image pixels per channels**
  - **high precision, long integration, cooled CCD sensors**



# Simultaneous Multispectral Imaging

## Simultaneous Multispectral Imaging System




<b>Wavelength Range</b>	420 nm to 700 nm	6 or 12 selections, continuous range
<b>Spectral Resolution</b>	3 nm, 9 nm, or 15 nm	Programmable, user defined *
<b>Spatial Resolution</b>	500 resolvable elements	Rayleigh criteria *
<b>Throughput Efficiency</b>	greater than 80%	peak at center wavelength for each of two polarized fields

*\* spectrally dependent*

# Simultaneous Multispectral Imaging

**PSI**  
Photonic Systems  
Incorporated

## System Schematic






Photonic Systems  
Incorporated

# Simultaneous Multispectral Imaging

## Spectral Passband Map



# Simultaneous Multispectral Imaging



Photonic Systems  
Incorporated

## Design Methodology

- **FORTTRAN software to model an arbitrary AOTF within CodeV from Optical Research Associates**
  - User Define Surface interface for CodeV
  - Pseudo-normal allows CodeV to "refract" ray into proper direction
  - Only runs on VAX (DEC) or Sparc (Sun) platforms
  - Too slow for system optimization
- **Stand-alone, custom software written in C to optimize an arbitrary AOTF using dispersive compensation optics**
  - Physical optics ray tracing in AOTF crystal
  - Traces rays through a variety of compensation optics types
  - Damped Least Squares optimization of compensation optics
- **Candidate compensation designs returned to CodeV for critical system performance assessment**

# **Simultaneous Multispectral Imaging**




---

**Residual errors for increasing degrees of design freedom**

- **Wegged AOTF to compensate dispersive aberrations**
- **Compensation residuals for 2 degrees of freedom**
- **Compensation residuals for 3 degrees of freedom**

# Simultaneous Multispectral Imaging


## Wedged AOTF compensation residuals



$\pm 3.0^\circ$  FOV, 512 pixels  
 0.0117° per pixel

# Simultaneous Multispectral Imaging


Compensation residuals for 2 degrees of freedom



$\pm 3.0^\circ$  FOV, 512 pixels  
 0.0117° per pixel

# Simultaneous Multispectral Imaging

Compensation residuals for 3 degrees of freedom





$\pm 3.0^\circ$  FOV, 512 pixels  
 0.0117° per pixel



# Simultaneous Multispectral Imaging

SMIS optical design performance for AOTF, compensation and custom image objective



- **Pixel subtends 19 by 19 microns for the SMIS system.**
- **The registration for the center of the image is well within 4 microns**
- **The edges of the image register within no more than 9 microns.**

# Simultaneous Multispectral Imaging



Photonic Systems  
Incorporated

## Acoustic Transducer Design


- **Acoustic beam side-lobes give spatially shifted "ghost" images**
- **Transducer design issues:**
  - Absolute minimum energy in acoustic beam sidelobes - transducer shape and apodization
  - Segmented transducer scheme to adjust raw transducer impedance for RF matching.
- **Manhar Shar of MVM Electronics developed novel transducer scheme that addresses these issues and provides excellent performance for the SMIS and future image sensor developments.  
(Patent forthcoming)**

# Simultaneous Multispectral Imaging




Photonic Systems  
Incorporated

## Acoustic Transducer Performance



Early AOTF Prototype



Final AOTF Design

# Simultaneous Multispectral Imaging



Photonic Systems  
Incorporated

## Prototype Performance

---

- **SMIS is currently in the fabrication and integration process.**
- **Preliminary results are limited to the lab bench breadboard optical system.**
- **Video tape very quickly made; please accept my apologies.**

# **Simultaneous Multispectral Imaging**



**Photonic Systems  
Incorporated**

## **Conclusion**

- **PSI and MVM Electronics have developed a completely compensated tunable camera system**
  - provides for simultaneous multispectral imaging
  - gives polarimetric data when appropriate
  - allow system to be extended with additional channels
  - provides a broad band image port
- **Compensation provides fraction of a pixel image registration for all points in the image over the entire spectral band.**
- **Compensation optics are designed externally to the AOTF**
  - represent a reduced cost compared to high precision wedges in the AOTF crystal fabrication.
  - provides adjustment for AOTF fabrication variance at the time of system integration and thus improves the yield of acceptable AOTF devices

## **Simultaneous Multispectral Imaging**

---



**Photonic Systems  
Incorporated**

### **Credits**

**PSI and MVM would like to thank Dr. Robert Nelson, of the NASA Jet Propulsion Laboratories, for his encouragement, guidance, and support. Without the funding from the NASA Small Business Innovative Research grant sponsored by Dr. Nelson, this important technology would not be available to the research and commercial communities.**



## Polarimetric Hyperspectral Imaging Systems and Applications

Li-Jen Cheng, Colin Mahoney, George Reyes, and Clayton La Baw  
Center for Space Microelectronics Technology  
Jet Propulsion Laboratory  
California Institute of Technology  
Pasadena, CA 91109

and

G.P. Li  
Department of Electrical and Computer Engineering  
University of California  
Irvine, CA 92717

\* Sponsored by NASA, ASTRO, MCSC, and SSDC

**AOTF IS:**

**A REAL-TIME PROGRAMMABLE,  
HIGH-RESOLUTION SPECTRAL BANDPASS FILTER  
WITH POLARIZATION BEAM SPLITTING CAPABILITY**

*incorporated with focal plane detector array(s), optics,  
& electronic subsystems*

**Polarimetric Hyperspectral Imaging Instrument****Image Data Set****As Function Of Wavelength And Polarization**

with spectral resolution adequate for material characterization





## **Advantages of AOTF-PHI System**

**Real-time collection of image data**

**Spectral  
Polarization  
Time variation.**



**Operational flexibility, fast programmable**


**Take only needed data at desired wavelengths.**

**Compact, light-weight, reliable, and low cost**

**Use on space and airborne platforms, ground vehicles,  
and hand-held.**

# ACOUSTO-OPTIC TUNABLE FILTER (AOTF)







with polarization electric vectors orthogonal to each other

Signal at each pixel in the cube is light intensity  
that can be converted into other physical parameters  
such as:

**spectral derivative images**  
**polarization difference images**




**JPL**



FT. HUACHUCA, AZ  
Vegetation Classification  
Polarization Effect

LJC/9/83

**JPL****AOTF SPECTRAL IMAGES**

H



0.67

0.55  $\mu$ 

V




0.73




LJC/93

# JPL

## SPECTRAL DERIVATIVE IMAGES AT CHLOROPHYLL RED EDGE



0.742



0.734



0.722


$\mu\text{m}$



0.710



0.699



0.688

$\mu\text{m}$

LJC/10/93


## A DETECTION CONCEPT ILLUSTRATION




Via Detecting Mask  
Generated  
with Expected Characteristics







## POLARIZATION IMAGES




$(I_v - I_h)/(I_v + I_h)$



Inverted




0.622 0.559 0.521 μm  
LIC/10/93

**JPL****A Camouflaged Target**


color image  
taken by a  
35mm camera



differential  
polarization image  
at 0.56 micron  
 $P = (I_v - I_h) / (I_v + I_h)$



original



inverted


Enlarged images of  
camouflaged target

LJC/10/23


# AEROSOL SCATTERING IN ATMOSPHERE

**JPL**

## Reflectance Spectra of Two Oaks at Different Distances



# Wavelength Dependence of Scattered Light Due to Aerosol in the Atmosphere




**JPL**

## **TARGET DETECTION AND CLUTTER REMOVAL**



**35 MM COLOR IMAGE  
USING AN ORDINARY CAMERA**




**DIFFERENTIAL POLARIZATION IMAGE  
AT 0.52 MICRONS**

## **MINES IN ICEPLANT FIELD**

LJC/4/94


minepol3.tif

# **JPL MINES IN ICEPLANT FIELD POLARIZATION SPECTRAL IMAGES**



# SPECTRAL MIXING

due to scattered light from neighboring objects



Ice: iceplant field (~400 m)

Dirt: bare ground with a white trailer nearby (~400 m)


Big: close distance (~40 m)

dark green round metallic mine






**VEGETATION  
AND  
POLARIZATION EFFECTS**

## Measured Polarization Spectra of Three Different Trees




# GREEN LEAF SPECTRA

phase angle = 20





# REFLECTIVE SPECTRA OF OLIVE LEAF AT SPECULAR ANGLE




With polarization parallel (||) and perpendicular (⊥)  
to incident plane

# REFLECTIVE AND DERIVATIVE SPECTRA OF EUCALYPTUS LEAF AT SPECULAR ANGLE



## POLARIZATION SPECTRA OF GREEN LEAVES



differential polarization =  $(I_{\perp} - I_{\parallel}) / (I_{\perp} + I_{\parallel})$

phase angle = 125 degrees


## **CHARACTERIZATION OF SILICON-ON-SILICON USING AOTF-PHI**

**Silicon-On-Silicon (SOS)**

**is**

**A most promising material  
of silicon-on-insulators,  
important for future advanced VLSI.**

## EXPERIMENTAL SETUP



**WHITE-LIGHT INTERFERENCE PATTERN**  
as a function of wavelength  
at two orthogonal polarizations



## WHITE-LIGHT INTERFERENCE IMAGE CUBE



interference spectrum



layer thickness maps  
deviations from model

interference amplitude  
reduction and DC component





surface/interface roughness

polarization images




surface/interface topographies  
abnormal interface structures



## Interference Images

## Interference Amplitude Map



0.550  $\mu$



0.574  $\mu$



perpendicular

to incident plane



parallel


Defined as  
( $I_{\max} - I_{\min}$ )

## SEH/AcuThin SOI Sample

LJC/9/94

## MAPS OF SILICON AND OXIDE LAYER THICKNESS WITH CORRELATION FACTOR BETWEEN MODEL AND MEASURED SPECTRA


Silicon



Oxide



Correlation



Mean	206.4 nm	1014.7 nm	0.9821
Stddev	5.90 nm (2.96%)	3.48 nm (0.34%)	0.0046 (0.46%)

SEH/AcuThin SOI Sample






Chart1



**JPL**

**MICROSCOPIC AOTF IMAGES OF  
AN INDIVIDUAL FET TEST DEVICE  
ON A VLSI WAFER**



vertical  
polarization



horizontal  
polarization

AT 0.685 MICRONS

11c

## **1.2-2.4 Micron Infrared Airborne Prototype System (Under Development)**

- Compact folded optical configuration.
- Simultaneous two-polarization imaging side-by-side on one Rockwell cooled focal plane array of HgCdTe. (a low-cost approach).
- Through-the-system video tracking.
- Real-time instrument capable of collecting an image cube data in Seconds.
- TeO<sub>2</sub> AOTF designed and manufactured by Aurora.

## Important Spectral Features in 1.2-2.4 micron.

- **Two major absorption bands due to H<sub>2</sub>O and CO<sub>2</sub> in the atmosphere.**

No useful solar are available at the wavelength of these two band.



- **Characteristic Spectral Signature of Man-Made Materials**

Textures and paints are often made of synthetic materials, originally from petroleum products. These products often have characteristic absorption bands at 1.7 and 2.3 microns. This also applies to camouflaged cloths and painted surface. Consequently, the capability to detect these bands will provide an effective classification process for military applications

ljc




## Comparison of Camouflaged Net and Natural Materials in Reflectance Spectrum



# NEW AND WEATHERED WHITE PLASTIC GARDEN TUBES

solid line: new  
dashed line: weathered



## Distribution

Admnstr  
Defns Techl Info Ctr  
Attn DTIC-OCP  
8725 John J Kingman Rd Ste 0944  
FT Belvoir VA 22060-6218

ERDEC  
Attn SCBRD-RTE-E3549 J O Jensen  
Attn CAPT A C Samuels  
APGEA Edgewood MD 21010-5423

Hdqtrs Dept of the Army  
Attn DAMO-FDQ MAJ M McGonagle  
Attn DAMO-FDQ D Schmidt  
400 Army Pentagon  
Washington DC 20310-0460

Night Vsn Dirctr  
Attn L J Mizerka  
10221 Burbeck Rd Ste 430  
FT Belvoir VA 22060-5806

US Military Academy  
Dept of Mathematical Sci  
Attn MAJ D Engen  
West Point NY 10996

Nav Rsrch Lab  
Attn Code 5603 I Aggarwall  
Attn Code 5603 D Daganias  
Washington DC 20375

Oak Ridge Natl Lab  
Attn T Vo-Dinh  
PO Box 2008 MS 6101  
Oak Ridge TN 37831-6101

Case Western Reserve Univ  
Dept of Electrl Engrg  
Attn D A Smith  
Cleveland OH 44106

Institute of Crystallography  
Attn Y Pisarevsky  
Moscow  
Russia

Marquette Univ Dept of Chemistry  
Attn C Tran  
PO Box 1881  
Milwaukee WI 53201

Moscow State Univ Dept of Physics  
Attn V Voloshinov  
Moscow 119899  
Russia

ST Petersburg State Academy of  
Aerospace Instrmntn  
Attn V V Kludzin  
Attn V V Molotok  
67 B Morskaya Str  
ST Petersburg 100000

Univ of California  
Dept of Elect & Computer Engrg  
Attn C S Tsai  
Engineering Gateway Bldg  
Irvine CA 92697

Univ of Pittsburgh  
Chevron Science Center  
Attn J Turner  
Room 314  
Pittsburgh PA 15260

J Goodell  
1201 Southview Rd  
Baltimore MD 21218

Advncd Materials Corp  
Attn C J Thong  
Attn M Uschak  
Attn S G Sankar  
Attn S Simizu  
700 Technology Dr Ste 3311  
Pittsburgh PA 15230-2950

Aurora Assoc  
Attn I C Chang  
3350 Scott Blvd B-20  
Santa Clara CA 95054

## Distribution

Brimrose Corp of America  
Attn S Trivedi  
Attn V Pelekhaty  
Attn W J Danley  
5020 Campbell Blvd  
Baltimore MD 21236

Brookhaven Natl Lab  
Attn C L Chen  
Bldg 197C DAT/SSN  
Upton NY 11973

Brookhaven Natl Lab  
Attn D Heglund  
Box 5000 Bldg 701  
Upton NY 11973

Carnegie Mellon Rsrch Instit  
Attn M Gottlieb  
Attn B Kaminsky  
Attn L J Denes  
700 Technology Dr PO Box 2950  
Pittsburgh PA 15230-2950

Central Design Bureau for Unique  
Instrmnt  
Attn V I Pustovoit  
Moscow 117342  
Russia

Jet Propulsion Lab  
Attn M/S 300-329 L-J Cheng  
4800 Oak Grove Dr  
Pasaolena CA 91109

Massachusetts Instit of Techlgy  
Attn Piotr Becla  
Room 13-4111  
Cambridge MA 02139

Natl Instit of Health  
Attn E N Lewis  
Bldg 5 Room B1-38  
Bethesda MD 20892

Neos Technologies Inc  
Attn E Young  
4300C Fortune Pl  
Melbourne FL 32904

Photonic Sys Inc  
Attn J A Carter III  
Attn D R Pape  
1800 Penn Stret Ste 6  
Melbourne FL 984-8181

Army Rsrch Lab  
Attn AMSRL-PS-ED J S Himmel  
FT Monmouth NJ 07703-5601

US Army Rsrch Lab  
Attn AMSRL-WM-PC A W Miziolek  
Attn AMSRL-WT-PC E D Lancaster  
Attn AMSRL-WT-PC K L McNesby  
Aberdeen Proving Ground MD 21005-5066

US Army Rsrch Lab  
Attn AMSRL-CI-LL Tech Lib (3 copies)  
Attn AMSRL-CS-AL-TA Mail & Records  
Mgmt  
Attn AMSRL-CS-AL-TP Techl Pub  
(3 copies)  
Attn AMSRL-IS-EE J B Gillespie  
Attn AMSRL-SE-SS C DeLuca  
Attn AMSRL-SE-EO N Fell  
Attn AMSRL-SE-E J Pellegrino  
Attn AMSRL-SE-EO A Filipov  
Attn AMSRL-SE-EO N Gupta (5 copies)  
Attn AMSRL-SE-ES D McCarthy  
Adelphi MD 20783-1197

REPORT DOCUMENTATION PAGE			Form Approved OMB No. 0704-0188	
Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.				
1. AGENCY USE ONLY (Leave blank)		2. REPORT DATE February 1997		3. REPORT TYPE AND DATES COVERED Final, from Jan 1996 to Jan 1997
4. TITLE AND SUBTITLE Viewgraph Supplement to the Proceeding of 1st ARL AOTF Workshop			5. FUNDING NUMBERS PE: 65709A	
6. AUTHOR(S) Neelam Gupta, Editor				
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) U.S. Army Research Laboratory Attn: AMSRL-SE-EO 2800 Powder Mill Road Adelphi, MD 20783-1197			8. PERFORMING ORGANIZATION REPORT NUMBER ARL-SR-54-S	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) U.S. Army Research Laboratory 2800 Powder Mill Road Adelphi, MD 20783-1197			10. SPONSORING/MONITORING AGENCY REPORT NUMBER	
11. SUPPLEMENTARY NOTES AMS Code: P665709.650 ARL Proj: AN7NEGAA				
12a. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release; distribution unlimited.			12b. DISTRIBUTION CODE	
13. ABSTRACT (Maximum 200 words)  Acousto-optic tunable-filter (AOTF) technology is a recent development that offers potential for rapid, frequency-agile tuning over a large optical wavelength range. An AOTF is an electronically tunable phase grating set up in an anisotropic crystal by the propagation of an ultrasonic wave in the crystal. Such filters have many attractive features, such as small size, lightweight, computer controlled operation, large optical wavelength range of operation, and no moving parts; and their operation can be made ultrasensitive by the use of advanced signal processing algorithms. These filters are being used in many applications such as the design of new spectroscopic instruments, remote detection and monitoring of chemicals, optical communication networks, tuning of laser cavities, etc.				
14. SUBJECT TERMS AOTF, spectrometer, chemical sensing, biological sensing, imaging			15. NUMBER OF PAGES 181	
			16. PRICE CODE	
17. SECURITY CLASSIFICATION OF REPORT Unclassified	18. SECURITY CLASSIFICATION OF THIS PAGE Unclassified	19. SECURITY CLASSIFICATION OF ABSTRACT Unclassified	20. LIMITATION OF ABSTRACT UL	